

### **SPECIAL OPTIONS:**

- E = Indicates that the base is painted with a gray epoxy enamel for improved corrosion resistance.
- EH = Combination of options E and H.  
(Gray Epoxy painted base and space heater)
- H = Indicates that a space heater is installed. Space heater input voltage is the same as the reset coil.

### **NOTES:**

1. Instruments with a 240 VAC coil are not CSA Certified.  
Instruments with a DPDT switch and a space heater are not CSA certified.
2. For instruments with a 240 V reset coil it is recommended that the field wiring, which may come into contact with the large resistor located inside of the Vibraswitch, have an insulation rated 125 degrees centigrade or higher.

## **MANUAL SUPPLEMENT**

### **Vibraswitch**

### **Model 365 and 366**

### **AC / DC RESET COIL**

**ROBERTSHAW  
TENNESSEE DIVISION**

**P.O. Box 400  
Knoxville, TN 37901-0400**

**Telephone (615) 546-0550**

**NU  
909S1**

**May  
COS 85820-**