

TABLE OF CONTENTS

SECTION	PAGE
1) <i>DESCRIPTION</i>	1-1
1.1 Description	1-1
1.2 Model Identification	1-1
2) <i>SPECIFICATIONS</i>	2-1
2.1 Environmental	2-1
2.2 Electrical	2-1
2.3 Performance	2-1
3) <i>INSTALLATION</i>	3-1
3.1 General	3-1
3.2 Mounting	3-1
3.3 Space Heater	3-5
3.4 Wiring	3-5
4) <i>OPERATION</i>	4-1
4.1 Operation	4-1
4.2 Adjustment of Operating Setpoint	4-2
5) <i>MAINTENANCE</i>	5-1
5.1 Troubleshooting	5-1

LIST OF ILLUSTRATIONS

FIGURE	PAGE
3-1 Mounting Dimensions and External Wiring for the Vibraswitch, Model 366	3-2
3-2 (Sheet 1 of 2) Methods of Mounting the Vibraswitch, Model 366	3-3
3-2 (Sheet 2 of 2) Methods of Mounting the Vibraswitch, Model 366	3-4
4-1 Operation Principle for the Vibraswitch, Model 366	4-1
4-1 Setpoint Adjustment	4-3
4-3 Setpoint Alarm Settings	4-4