

**INSTRUMENT PART NUMBER: MODELS 365 and 366 with a reset
coil rated 117V AC / DC or higher**

Refer to Instruction Manual No. 909GF083 (for Model 365) or 909GF084 (for Model 366) and all other supplements which may have been supplied with the instrument for all instructions and specifications except as may be noted in this supplement.

When DC voltage is to be employed for energizing the reset coil, the wiring for the reset coil must be polarized as follows.

Connect the positive (+) wire to terminal # 1.
Connect the minus (-) wire to terminal # 2.